# **GUARDIAN SOLO**

**CATERING VERSION** 

Marine Lone Worker Protection

Information Brochure



C-VIGIL Ltd: marine (CVM)

In association with



C-VIGIL Ltd : marine (CVM)
GUARDIAN SYSTEMS





Establishing a healthy and safe working environment for lone workers can be different from organizing the health and safety of other crew members - they should not be put at more risk than other crew working onboard.

It will often be safe to work alone. However, managers should think about and deal with any health and safety risks **before** people are allowed to do so.

One option is to provide these crew members with lone worker protection and emergency calling equipment; thereby improving the chances of a successful outcome should the worst happen.

Protection can be provided for: -

- Engineering Areas
- Catering Areas
- Deck Areas (Portable Units)

Remember – it's better to have it and not need it, then to need it and not have it!

Automatic Wireless Lone Worker
Protection & Emergency Calling System

# Automatic Interval Timer Reset Within the Catering Areas Using PIR Motion Sensors



SOLO is intended to supplement any existing protection system already in place.

It is often the case that the catering staff - quite often a single person - will find their selves alone in the catering areas / galley for protracted periods i.e. during meal preparations, cooking, washing down...etc.

SOLO is intended to supplement any existing protection systems already in use.

It is often the case that catering workers will find their selves alone in the catering areas – galley, preparation areas, storage, fridges...etc. during their normal duties.

SOLO protects workers whilst in the catering areas by detecting their movements using PIR motion sensors. Detected movement automatically resets the interval timer.

Should a worker remain motionless, through incapacity or otherwise, the interval timer will expire, causing the staged alarms to be triggered.



**Wireless Reset Transmitter & Receiver** 

Strategically placed wireless receivers allows for portable on the move interval timer resetting and emergency alerting from anywhere in the catering areas and other designated work spaces

### **Staged Alarms**

#### 1st Stage - Pre-alarm

- MCU panel sounder & LED operate intermittently
- + 2 minutes

## 2<sup>nd</sup> Stage – Main Local Alarm

- MCU panel sounder & LED operate constantly
- Bridge Alarm & Indicator operates

#### + 3 minutes

#### 3<sup>rd</sup> Stage – Engine Room Alarm

- MCU panel sounder & LED operate constantly
- Bridge Alarm & Indicator operates

#### +5 minutes

• Engine room alarm activated

The interval timer can be reset at any time using the portable wireless key-fob transmitter or using any of the manual reset panels (if fitted). The key-fob transmitters are paired with receivers fitted around the catering areas (number depends on the size of the vessel).

Manual reset buttons (MCU or Manual Reset Panels) and/or key-fob button #1: -

- One short press (< 3 secs) resets the interval timer.
- One long press (> 3 secs) activates a "Call-for-Assistance" this bypasses the interval timer and triggers the staged alarms immediately.

# Key-fob button #2: -

• Sounds local alarm for as long as it's pressed.

A 140db portable personal alarm can be provided to help in the location of the injured person.





# **Optional Extras**


Additional key-fob transmitters

Additional wireless reset/emgy call receivers

Additional manual reset/emgy call PB panels

Full Turnkey Projects
Bespoke Design, Cabling Installation
Testing & Commissioning

# **System Overview**





#### MCU



MCU – fitted within the catering area in a position allowing easy access.

The MCU contains: -

Pre-Alarm – flashing blue LED & pulsing 80dB sounder

Time Period Selector – rotary selector switch

Reset / Call for Assistance – short press (<3 secs) resets interval period timer. Long press (>3 secs) Call for Assistance

Timer On – Off – Set / Reset interval timer.

*Elapsed Time Counter* – displays how long period timer has been running.

Power On / Off – switches system on / off

# MANUAL RESET/EMGY CALL PUSH BUTTON PANEL



Mushroom pushbutton head – for ease of use
High intensity LED indicator
IP65

# PORTABLE WIRELESS RESET/EMGY CALL KEY-FOB TRANSMITTER



868MHz license fee frequency

150m range

2 button operations

Long battery life (+5 years)

# WIRELESS RESET/EMGY CALL RECEIVER



868MHz license free operation

RS232 serial data communication supported

1Km range

Many-to-one operation

Hard ABS IP68 Case

Lone Worker Systems

Wind Turbines Safety

CCTV Systems

Acoustic Area Denial Remote <sup>o</sup>C monitoring

Lift Car Indication

# PIR MOTION DETECTOR



15m detection range

Dual sensor for increased sensitivity

Anti-tamper

# LOCAL ALARM SOUNDER/BEACON



High output industrial sounder
Multi-tone selection
100dB @ 1m
IP65

# **BRIDGE ALARM & INDICATOR PANEL**



Alerts bridge staff to possible situation catering areas
Interval timer – on-off LED indication
Audible alarm sounder with silence button



Remote °C monitoring





www.cvigil.co.uk

www.kvasir-group.com

C-VIGIL Ltd: marine (CVM)

**Bryntirion Rd** 

**BAGILLT, Flintshire** 

CH6 6DS, UK

+44 (0)1244 879 279

general@cvigil.co.uk

www.cvigil.co.uk

Company Reg No. 0447624

VAT Reg No. 804 6004 68

ISO 9001 Reg No. 2001 654

l Remote <sup>o</sup>C monitoring